

RF Card Reader Manual

STAR 100R/P

<입력방법>

| | | | |
|----------------|---------------------------|----------------------|--|
| MASTER CARD 등록 | MODE "01" | : RF CARD 등록 | "01" ENTER -> MASTER CARD 읽음 -> 등록 CARD 읽음 -> MASTER CARD 읽음 -> PASSWORD 4자리 등록후 ENTER 치고 종료 |
| | MODE "02" | : RF CARD + PASSWORD | "02" ENTER -> MASTER CARD 읽음 -> 등록 CARD 읽음 -> MASTER CARD 읽음 -> PASSWORD 4자리 등록후 ENTER 치고 종료 |
| | MODE "03" | : PIN NUMBER 등록 | "03" ENTER -> MASTER CARD "6" 자리 등록 -> 등록할 NUMBER "4" 또는 "6" 자리 등록 -> MASTER NO 등록후 종료 |
| CARD 등록 | MODE "11" | : RF CARD 추가등록 | MASTER CARD 읽음 -> "11" ENTER -> 등록 CARD 읽음 -> MASTER CARD 읽고 종료 |
| | MODE "12" | : PIN NUMBER 추가등록 | MASTER NO 등록 -> "12" ENTER -> PIN NUMBER 등록 -> MASTER PIN NUMBER 등록후 종료 |
| | MODE "14" | : CARD 삭제 | MASTER CARD 읽음 -> "13" ENTER -> 삭제할 RF CARD 번호 "8자리" 또는 PIN NUMBER를 입력후 ENTER 치면 삭제됨 |
| | MODE "21" | : LOCK TIME 설정 | MASTER CARD 읽음 -> "21" ENTER -> TOTAL +ENT -> LOCK(03)+ENT -> ALARM(00)+ENT -> TTL(00)+ENT -> BUZZ(00)+ENT -> LED(03)+ENT 종료 |
| | MODE "73" | : RF CARD PIN ENABLE | MASTER CARD 읽음 -> "73" ENTER |
| | MODE "99" | : 기계초기화 | MASTER CARD 읽음 -> "99" ENTER |
| | (LOCK RELAY 초기 설정값은 "3초") | | |

STAR 100R/P

<입력방법>

| | | | |
|----------------|---------------------------|----------------------|--|
| MASTER CARD 등록 | MODE "01" | : RF CARD 등록 | "01" ENTER -> MASTER CARD 읽음 -> 등록 CARD 읽음 -> MASTER CARD 읽음 -> PASSWORD 4자리 등록후 ENTER 치고 종료 |
| | MODE "02" | : RF CARD + PASSWORD | "02" ENTER -> MASTER CARD 읽음 -> 등록 CARD 읽음 -> MASTER CARD 읽음 -> PASSWORD 4자리 등록후 ENTER 치고 종료 |
| | MODE "03" | : PIN NUMBER 등록 | "03" ENTER -> MASTER CARD "6" 자리 등록 -> 등록할 NUMBER "4" 또는 "6" 자리 등록 -> MASTER NO 등록후 종료 |
| CARD 등록 | MODE "11" | : RF CARD 추가등록 | MASTER CARD 읽음 -> "11" ENTER -> 등록 CARD 읽음 -> MASTER CARD 읽고 종료 |
| | MODE "12" | : PIN NUMBER 추가등록 | MASTER NO 등록 -> "12" ENTER -> PIN NUMBER 등록 -> MASTER PIN NUMBER 등록후 종료 |
| | MODE "14" | : CARD 삭제 | MASTER CARD 읽음 -> "13" ENTER -> 삭제할 RF CARD 번호 "8자리" 또는 PIN NUMBER를 입력후 ENTER 치면 삭제됨 |
| | MODE "21" | : LOCK TIME 설정 | MASTER CARD 읽음 -> "21" ENTER -> TOTAL +ENT -> LOCK(03)+ENT -> ALARM(00)+ENT -> TTL(00)+ENT -> BUZZ(00)+ENT -> LED(03)+ENT 종료 |
| | MODE "73" | : RF CARD PIN ENABLE | MASTER CARD 읽음 -> "73" ENTER |
| | MODE "99" | : 기계초기화 | MASTER CARD 읽음 -> "99" ENTER |
| | (LOCK RELAY 초기 설정값은 "3초") | | |